

EXNO: 04
06/08/2024

PRACTICAL - 4

100%

setup and configure a Local area Network using a switch and ethernet cable in your lab

What is LAN

A Local area Network (LAN) refers to a network that connects devices within a limited area such as an office building, school or home. It enables users to share resources including data, printers and internet access.

How to set up a LAN

Step 1: plan and design an appropriate network topology taking into account network requirements and equipment location

Step 2: you can take 4 computers, a switch 8, 16, or 24 ports which is sufficient for network of this size and a 4 ethernet cable

Step 3: connect your computers to network switch via an Ethernet cable which is as simple as plugging one end of the Ethernet cable into your computer and the other end into your network switch

Step 4: Assign IP address to your PC

1) Log on to the client computer as Administrator or a owner

2) click network and internet connection

3) Right click LAN/ ethernet \rightarrow this is a properties \rightarrow select internet protocol (IPv4/TCP) \rightarrow click on properties \rightarrow select use the following IP address option and assign IP address

\rightarrow similarly assign IP address to all the PC's connected to switch
PC1-IP address: 10.1.1.1 / Subnet mask 255.0.0.0
PC2-IP address: 10.1.1.2, Subnet mask 255.0.0.0

Step 5: configure a network switch

1) connect your computer to the switch to access the switch '3' web interface, you will need to connect your computer to switch using a ethernet cable

2) Log in to web interface: open a web browser and enter the IP address of the switch in the address bar this should bring up the login page for the switch's web interface. Enter the username and password to log in

3) configure basic settings once you logged in you will able to configure basic settings for the switch

Assign IP address as: 10.1.1.3
subnet mask 255.0.0.0


Step 6: Check the connectivity between switch and other machine by using ping command in the command prompt of the device

Step 7: select a folder \rightarrow go to properties \rightarrow click sharing tab \rightarrow share it with everyone on the same LAN

Step 8: Try to access the shared folder from other computers of the network

Student observation:

Draw a neat diagram of the LAN in configuration of observation book that you have implemented in your lab. write the IP configuration of each and every device with the outcome and challenge faced while configuration of the LAN.



8/6/24

RESULT

Thus setup and configure a LAN chord network using a switch and Ethernet cable is connected